gfdhomes.co.uk | 01642 309 576

Infill side panel fitting instructions

Install your Solidor and side panel in the same manner as usual ensuring regular fixings and that the frame is square and plumb.



Offer the infill side panel to the outer frame using the 3 locating / fixing lugs to help with alignment.

The lugs are positioned to give ideal compression, the use of 4mm packers may be required to help achieve an even air gap.



Apply pressure to the opposite side to give an all round even compression against the gasket.

Once the gap between the infill side panel and outer-frame is even, fix by screwing through the door frame, coupler and side panel frame into the infill side panel using a screw of sufficient length.



Congratulations you have now installed a Solidor composite door and infill side panel combination.



Infill side panel fitting instructions

Install your Solidor and side panel in the same manner as usual ensuring regular fixings and that the frame is square and plumb.



Offer the infill side panel to the outer frame using the 3 locating / fixing lugs to help with alignment.

The lugs are positioned to give ideal compression, the use of 4mm packers may be required to help achieve an even air gap.



Apply pressure to the opposite side to give an all round even compression against the gasket.

Once the gap between the infill side panel and outer-frame is even, fix by screwing through the door frame, coupler and side panel frame into the infill side panel using a screw of sufficient length.



Congratulations you have now installed a Solidor composite door and infill side panel combination.

